

# User's Information & Installation Instructions

## Inducer Orifice Selection

Refer to the tables below to select the appropriate orifice size for this replacement kit. The orifice size can also be found on the back side of each orifice.

### UPFLOW/HORIZONTAL UNITS:

CABINET SIZE	INPUT (MBTUH)	ORIFICE SIZE (INCHES)*
A	38	0.88 [SC] / 0.62 [SD]
B	46	0.94
B	54	0.94 [SC] / 0.75 [SD]
B	60	0.88 [TC] / 1.00 [MQ]
B	61	1.00
B	72	1.00
C	72	1.16 [SC] / 0.88 [SD]
C	76	1.38
C	80	1.00
C	90	1.38 [SC] / 1.13 [SD]
C	100	1.25
D	108	N/A [SC] / 1.16 [SD]
D	120	N/A [TC/MQ] / 1.38 [SD]

### DOWNFLOW UNITS:

CABINET SIZE	INPUT (MBTUH)	ORIFICE SIZE (INCHES)*
B	54	0.94 [SL] / 0.75 [SM]
B	60	0.75
B	72	1.00
C	72	0.88
C	80	0.97
C	90	1.13
C	100	1.31
D	118	1.38
D	120	N/A [SL] / 1.50 [TL]

\*NOTE: Model series in brackets where applicable

**NORDYNE**

COMPLETE COMFORT. GENUINE VALUE.

Specifications & illustrations subject to change without notice or incurring obligations.  
O' Fallon, MO | Printed in U.S.A. (08/11)



709211A (Replaces 7092110)